

Single Fault Fiter® Electronic Power Fuses Inverse-Curve-Type Control Modules

BASIS—The total clearing time-current characteristic curves shown above are applicable over the entire Fault Fiter Electronic Power Fuse operating temperature range of -40°C to +55°C (-40°F to + 131°F). No **APPLICATION**—The maximum continuous current-carrying capability of Fault Fiter Electronic Power Fuses is 600 amperes RMS, regardless of the control module selected.

IMPORTANT: Fault Fiter Electronic Power Fuse control modules must be selected by qualified persons knowledgeable in equipment protection and time-current coordination and who understand the consequences of improperly coordinated overcurrent protective devices. Failure to achieve complete coordination between Fault Fiter Electronic Power Fuses and source-side or load-side protective devices may result in improper operation of one or more Fault Fiter fuses.

adjustments must be made to these curves for ambient temperatures within this temperature range or to reflect self-heating caused by the flow of load current.

TOLERANCES-Curves are plotted to maximum test points; all variations are minus.

Because Fault Fiter Electronic Power Fuse time-current characteristics are electronically derived, they are not subject to change caused by aging, transient overcurrents, or fault currents. It is, therefore, unnecessary to replace Fault Fiter control modules following a fault-clearing operation only blown Fault Fiter interrupting modules need be replaced.



March 8, 2021 © S&C Electric Company 1984–2021, all rights reserved

TCC Number 410-7-2